



OPERATING INSTRUCTIONS



1 CHECK & CONNECT:

Ensure both slush tanks are securely clipped onto the base. This prevents leaks and spills!



2 ATTACH DRIP TRAY:

Remove the drip tray (stored inside one of the tanks) and clip it to the front of the machine.



3 PLUG INTO 16 AMP POWER:

Connect the machine to a 16 Amp wall power supply. Do not use generators.




4 FILL WITH SLUSH MIX:

Pour in the ready-to-use slush mix. Do not dilute. Do not exceed the MAX level line on each tank.



5 SWITCH ON (MAINS):

Turn the Main Switch to Position I (the "On" position). →



6 SET SWITCHES (VERY IMPORTANT):

Make sure your switches are set as per picture below. All switches must match the Main Switch (Position I).

CORRECT SWITCH CONFIGURATION (ON POSITION)



All switches must be set to POSITION I (ON) to operate.

SWITCH POSITIONS EXPLAINED:



POSITION I (ON)
Use this position to make slush.



POSITION II (DEFROST)
Use this position to defrost (at the end of the day).



7 WAIT TO FREEZE:


- ✓ Approx. 120 minutes to freeze with 10 litres per tank.
- ✓ For cocktails: add alcohol only once fully slushed.



8 TOPPING UP?

Use refrigerated slush mix to reduce re-freeze time.

SLUSH MACHINE



DIMENSIONS:

Height: 800mm x Width: 450mm x Depth: 500mm



POWER:

16 Amp / 230 Volt (Wall Power Only)



CAPACITY:

2 x 10 Litres (Max per tank)



FREEZE TIME:

Approx. 120 minutes with 10L per tank



CONTROL:

Main Switch + 2 Tank Switches
(All must match)



MODE:

Freeze Mode (I) / Defrost Mode (II)

THE PARTY'S OVER

1



Switch all switches to Defrost Mode (Position II).

2



Flush both tanks with cold water.
(No detergent, please!)

3



We'll deep clean the rest. Please return all empty slush mix bottles. (R20 charge per bottle not returned.)

IMPORTANT NOTES

- ⚠ Only 16 Amp power (wall power) may be used, no generators.
- ⚠ Only use the supplied slush mix. No substitutes!
- ⚠ Do not dilute – it won't freeze properly.
- ⚠ It will take approx. 120 minutes to freeze with 10 litres in each tank.
- ⚠ Don't adjust screen settings, those are for the pros!
- ⚠ If you need a flavour change, just rinse with cold water. No detergent please.

