



Caterkid

Fun Food Equipment and Events

MINI DOUBLE SLUSH MACHINE

Easy to use. Hard to resist!



OPERATING INSTRUCTIONS



1 CHECK & CONNECT:

Ensure both slush tanks are securely clipped onto the base. This prevents leaks and spills!



2 ATTACH DRIP TRAY:

Remove the drip tray (stored inside one of the tanks) and clip it to the front of the machine.



3 PLUG INTO 16 AMP POWER:

Connect the machine to a 16 Amp wall power supply. Do not use generators.



4 FILL WITH SLUSH MIX:

Pour in the ready-to-use slush mix. Do not dilute. Do not exceed the MAX level line on each tank.




5 SWITCH ON (MAINS):

Switch the green Mains Switch to ON (I).



6 SET MODES (VERY IMPORTANT):

Make sure your switches are set as per picture below. All switches must match the Main Switch (ON).



7 WAIT TO FREEZE:


- ✓ Approx. 90–120 minutes to freeze with 5 litres per tank.
- ✓ For cocktails: add alcohol only once fully slushed.



8 TOPPING UP?

Use refrigerated slush mix to reduce re-freeze time.

MINI DOUBLE SLUSH MACHINE



DIMENSIONS:

Height: 650mm x Width: 400mm x Depth: 400mm



POWER:

220 Volt / 3 Amp / 0.69 kW



CAPACITY:

2 x 5 Litre



FREEZE TIME:

Approx. 90–120 minutes with 5L per tank



CONTROL:

Mains Switch + 2 Mode Switches (All must match)



MODE:

Slush Mode (ON) / Defrost Mode (OFF)

THE PARTY